



Quality Refrigeration

OWNER'S MANUAL

**Instructions for the installation, operation
and maintenance of all Traulsen:**

Reach-In Even Thaw Refrigerator Models*

Reach-In Models*

**RET132EUT-FHS, RET132EUT-HHS, RET232EUT-FHS, RET232EUT-HHS,
RET232NUT-FHS & RET232NUT-HHS**

***For roll-in even-thaw models please refer to form number TR35867.**

This Traulsen unit is built to our highest quality standards. We build our refrigerators, freezers and heated cabinets this way as a matter of pride. This philosophy has made Traulsen the leader in commercial refrigeration since 1938. We thank you for your choice and confidence in Traulsen equipment and we know you will receive many years of utility from this equipment.

All Traulsen units are placed on a permanent record file with the service department. In the event of any future questions you may have, please refer to the model and serial number found on the name tag affixed to the unit. Should you need service, however, call us on our toll free number, 800-825-8220 between 7:30 am and 4:30 pm CST, Monday thru Friday. It is our pleasure to help and assist you in every possible way.

INSTALLER

COMPLETE THE FOLLOWING INFORMATION PRIOR TO UNIT INSTALLATION

INITIAL START DATE: _____ SERIAL NO. _____


MODEL TYPE: _____

COMPANY/INDIVIDUAL NAME: _____

INSTALLER: _____

TABLE OF CONTENTS



I. THE SERIAL TAG	Page 1	VI. OTHER	
II. RECEIPT INSPECTION	Page 2	a-Service Information	Page 5
III. INSTALLATION		b-Spare Parts	Page 5
a-Location	Page 2	c-Warranty Registration	Page 5
b-Packaging	Page 2	VII. GEN'L USE, OPERATION & SERVICE SUMMARY	Page 6
c-Installing Legs or Casters	Page 2	VIII. EXPECTED THAW PERFORMANCE/ OPERATIONAL TROUBLESHOOTING	
d-Tray Slides	Page 2	a-Introduction	Page 7
e-Cord & Plug	Page 3	b-Test Parameters	Page 7
f-Power Supply	Page 3	c-Test Results	Page 7
g-Wiring Diagram	Page 3	d-Results as a Function of Product Mix	Page 7
h-Clearance	Page 3	e-Incomplete Thawing	Page 7
IV. OPERATION		f-Equipment Issues	Page 7
a-Even-Thaw Overview	Page 3	g-Other Causes Of Extended Thaw Times	Page 7-8
b-Expected Performance	Page 3	IX. TROUBLE SHOOTING GUIDE	Page 8
c-Even-Thaw Operation	Page 3	X. SPARE PARTS LIST	Page 9
d-Batch Loading	Page 3	XI. WIRING DIAGRAM - ALL ONE SECTION MODELS	Page 10
e-Process Loading	Page 3	XII. WIRING DIAGRAM - MODELS RET232NUT ONLY	Page 11
f-Interior Arrangements	Page 3	XIII. WIRING DIAGRAM - MODELS RET232EUT ONLY	Page 12
g-Adjusting The Temperature Scale	Page 4	XIV. WARRANTY INFORMATION	Page 13
h-Operator Controls, Blower Switch	Page 4	XV. INDEX	Page 14
i-Call Service Light	Page 4		
V. CARE & MAINTENANCE			
a-Cleaning The Condenser	Page 4		
b-Hinge Replacement	Page 4		
c-Replacing The Gaskets	Page 5		
d-Cleaning The Exterior	Page 5		
e-Cleaning The Interior	Page 5		



FORT WORTH, TX.

SERIAL VOLTS	MODEL Hz	PH	
TOTAL CURRENT	AMPS		
MINIMUM CIRCUIT	AMPS		
MAXIMUM OVERCURRENT PROTECTION			AMPS
LIGHTS	WATTS		
HEATERS	AMPS		
REFRIGERANT DESIGN PRESSURE		TYPE HIGH	OZ LOW
REFRIGERANT DESIGN PRESSURE		TYPE HIGH	OZ LOW

370-60294-00 REV (A)

I. THE SERIAL TAG

The serial tag is a permanently affixed sticker on which is recorded vital electrical and refrigeration data about your Traulsen product, as well as the model and serial number. This tag is located in the upper right interior compartment on all reach-in/pass-thru and roll-in/roll-thru refrigerator, freezer and dual-temp models. For hot food models, this tag is located on the top of the unit behind the louvers to protect it from the heat.

READING THE SERIAL TAG

- Serial = The permanent ID# of your Traulsen
- Model = The model # of your Traulsen
- Volts = Voltage
- Hz = Cycle
- PH = Phase
- Total Current = Maximum amp draw
- Minimum Circuit = Minimum circuit ampacity
- Lights = Light wattage
- Heaters = Heater amperage (Hot Food units only)
- Refrigerant = Refrigerant type used
- Design Pressure = High & low side operating pressures and refrigerant charge
- Agency Labels = Designates agency listings

II. RECEIPT INSPECTION

All Traulsen products are factory tested for performance and are free from defects when shipped. The utmost care has been taken in crating this product to protect against damage in transit. All interior fittings have been carefully secured and the legs or casters are boxed and strapped inside to prevent damage. Door keys will be attached to the handle with a nylon strip. The handle is protected by an easily removable nylon netting.

You should carefully inspect your Traulsen unit for damage during delivery. If damage is detected, you should save all the crating materials and make note on the carrier's Bill Of Lading describing this. A freight claim should be filed immediately. If damage is subsequently noted during or immediately after installation, contact the respective carrier and file a freight claim. Under no condition may a damaged unit be returned to Traulsen without first obtaining written permission (return authorization).

III. INSTALLATION

III. a - LOCATION:

Select a proper location for your Traulsen unit, away from extreme heat or cold. Allow enough clearance between the unit and the side wall in order to make use of the door stay open feature at 120° (self-closing feature operates up to 90°). The door(s) must be able to open a minimum of 90° in order to make use of the maximum clear door width available.

III. b - PACKAGING:

All Traulsen units are shipped from the factory bolted to a sturdy wooden pallet and packaged in a durable cardboard container. The carton is attached to the wooden skid with the use of large staples. These should first be removed to avoid scratching the unit when lifting off the crate.

Most exterior stainless steel surfaces have a protective vinyl covering to prevent scratching during manufacturing, shipping and installation. After the unit is installed in place of service, remove and discard the covering from all surfaces.

To remove the wooden pallet, first if at all possible, we suggest that the cabinet remain bolted to the pallet during all transportation to the point of final installation. The bolts can then be removed with a 3/4" socket wrench. Avoid laying the unit on its front, side or back for removal of the pallet.

NOTE: Traulsen does not recommend laying the unit down on its front, side or back. However, if you must please be certain to allow the unit to remain in an upright position afterwards for 24 hours before plugging it in so that the compressor oils and refrigerant may settle.

6" high stainless steel legs are supplied standard for all Traulsen reach-in Even-Thaw models. Casters in

III. INSTALLATION (cont'd)

III. c - INSTALLING LEGS OR CASTERS:

lieu of legs are available as an optional accessory for the same models. These are shipped from the factory packed inside a cardboard box which is strapped to one of the shelves. Remove the nylon strap and open the box, it should contain either four (4) legs or four (4) casters and sixteen (16) bolts.

WARNING: THE CABINET MUST BE BLOCKED AND STABLE BEFORE INSTALLING LEGS OR CASTERS.

To install the legs or casters, first raise and block the reach-in a minimum of 7" from the floor. For installing legs, thread the legs into the threaded holes on the bottom of the cabinet (see figure 1). Be certain that all legs are tightly secured (legs and casters should be tightened to 300 inch/pounds, max). When the unit is set in its final position, it is important for proper operation that the unit be level. The legs are adjustable for this purpose, turn the bottom of the leg counter-clockwise to raise it, clockwise to lower it. Level the unit from front to back as well as side to side in this manner, using a level placed in the bottom of the cabinet.




Fig. 1

Please note that Traulsen units are not designed to be moved while on legs. If the unit requires moving, a pallet jack or forklift should be used to prevent damage. For installing casters, the casters are "plate" type, and require the use of four (4) bolts each to secure them firmly to the cabinet bottom at each corner (see figure 2). The caster bolts are tightened using a 1/2" socket wrench.




Fig. 2

III. d - TRAY SLIDES:

Reach-In models are supplied with fourteen (14) pairs of #1 type tray slides on 4" centers. These are shipped installed from the factory, and are easily removable for cleaning without tools.

III. INSTALLATION (cont'd)

III. e - CORD & PLUG:

Most self-contained models are supplied with a cord & plug attached. It is shipped coiled at the top of the cabinet, secured by a nylon strip. For your safety and protection, all units supplied with a cord and plug include a special three-prong grounding plug on the service cord. Select only a dedicated electrical outlet with grounding plug for power source. **NOTE:** Do not under any circumstances, cut or remove the round grounding prong from the plug, or use an extension cord.

III. f - POWER SUPPLY:

The supply voltage should be checked prior to connection to be certain that proper voltage for the cabinet wiring is available (refer to the serial tag to determine correct unit voltage). Make connections in accordance with local electrical codes. Use qualified electricians.

Use of a separate, dedicated circuit is required. Size wiring to handle indicated load and provide necessary overcurrent protector in circuit (see amperage requirements on the unit's serial tag).

III. g - WIRING DIAGRAM:

Refer to the wiring diagram for any service work performed on the unit. Should you require one, please contact Traulsen Service at (800) 825-8220, and provide the model and serial number of the unit involved.

III. h - CLEARANCE:

In order to assure optimum performance, the condensing unit of your Traulsen unit **MUST** have an adequate supply of air for cooling purposes. Therefore, the operating location must either have a minimum of 12" clearance overhead of the condensing unit or allow for unrestricted air flow at the back of the unit. Clearance of at least 12" above is required in order to perform certain maintenance tasks.

IV. OPERATION

IV. a - EVEN-THAW OVERVIEW:

The "Even-Thaw" refrigerator was specially designed to thaw frozen food product under safe, temperature controlled conditions. It is not intended as a storage refrigerator.

NOTE: USING THIS REFRIGERATOR FOR STORAGE OF UNCOVERED PRODUCT IS NOT RECOMMENDED.

IV. b - EXPECTED PERFORMANCE:

The Traulsen Even-Thaw refrigerator is designed to thaw a full load of frozen food product (see **BATCH LOADING** for guidelines) in approximately 18 to 24 hours. However, be aware that actual thawing times will vary depending upon a number of variables, such as product type, product packaging, density, spacing, etc. Please note that some other loading variables, such as product location, are not important to thawing and do not effect thaw cycle duration.

IV. OPERATION (cont'd)

IV. c - EVEN THAW OPERATION:

The Traulsen Even-Thaw cabinet is a refrigerator, with two important additional features: 1) the ability to introduce small amounts of heat into the cabinet, and 2) increased air flow, indicated by the presence of blowers mounted behind the mullion.

The Even-Thaw refrigerator operates continually, the introduction of frozen product lowers the cabinet temperature below the heater setpoint temperature (37°F). This prompts the refrigeration system to turn OFF, and the heaters to turn ON. Anytime the cabinet air temperature is below the heater setpoint temperature, additional heat is added. Heater operation is controlled proportionally, i.e. the colder the cabinet temperature, the longer the heaters remain in operation. When the cabinet air temperature reaches above the heater setpoint temperature, the heaters turn OFF.

When the cabinet air temperature reaches the upper refrigerator setpoint temperature (40°F), the refrigeration cycle is initiated. As long as product does not lower the cabinet temperature below the lower refrigeration setpoint temperature (37°F), the cabinet will continue to cycle between 38°F and 40°F. Upon completion of a thaw cycle, the thawed product should then be removed from the Even-Thaw cabinet and placed in a dedicated storage refrigerator.

IV. d - BATCH LOADING:

The Even-Thaw model can accommodate any size partial load, or up to twenty eight (28) 18" x 26" pans of product. Use of aluminum pans is highly recommended. Product should be placed on pans in one layer only to allow for proper air flow.

When completely loaded with frozen product (at approximately -5°F), the interior cabinet air temperature will begin to drop and approach the product temperature as a result. When this occurs the heaters begin operation in order to return the cabinet temperature back up to the heater setpoint temperature (37°F). This portion of the thaw cycle may take place for approximately 8 to 12 hours. With a full product load the interior cabinet temperature should remain at or below 37°F for approximately 8 to 12 hours of the expected 18-24 hour total thaw cycle time.

IV. e - PROCESS LOADING:

If the cabinet is unloaded as needed and replaced with frozen product, the average cabinet temperatures remain higher. A fully loaded cabinet with the refrigeration system cycling from 38°F to 40°F thaws product faster than one maintaining operation at below 32°F air temperatures for several hours.

IV. f - INTERIOR ARRANGEMENTS:

Each reach-in Even-Thaw model includes 14 pairs of #1 tray slides (16 gauge stainless steel angle type) for bottom support of either: (1) 18" x 26" pan per pair of tray slides or (2) 14" x 18" pans per pair of tray slides, per section.

IV. OPERATION (cont'd)

IV. g - ADJUSTING THE TEMPERATURE SCALE:

The Traulsen Even-Thaw model is preset at the factory to operate within strict temperature parameters. Should these settings require adjustment, please contact our Service Department at (800) 825-8220.

IV. h - OPERATOR CONTROLS, BLOWER SWITCH:

As delivered from the factory, all RET models are preset to operate as described in section IV B. However, if needed the unit can also be set to operate as a high capacity refrigerator.

To accomplish this a Blower Switch is located behind the cabinet louvers towards the center. It is labeled ON/OFF. As delivered, this is in the ON position, allowing the unit to operate in the even-thaw mode. When in the OFF position, this disables two internal mullion blowers, allowing the unit to operate as a high capacity refrigerator. Return the Blower Switch to the ON position prior to attempting another even-thaw batch. Failure to do so will result in increased thaw times.

IV. i - CALL SERVICE LIGHT:

This red light is located above the front panel thermometer. If illuminated, it may indicate a failure or problem with one of the temperature sensing probes inside the Even-Thaw unit. If one of the temperature sensing probes fail, the unit will default to a preset refrigeration cycle in an attempt to maintain safe product temperatures. The refrigeration system and fans will continue to function.

If the light is illuminated, the unit WILL NOT function in the thaw mode until the faulty component is repaired. If illuminated, contact your authorized service agent.

V. CARE & MAINTENANCE


V. a - CLEANING THE CONDENSER:

The most important thing you can do to insure a long, reliable service life for your Traulsen is to regularly clean the condenser coil.

The condensing unit requires regularly scheduled cleaning to keep the finned condenser clean of lint and dust accumulation. Keeping the condenser clean allows the cabinet to operate more efficiently and use less energy.

To clean the condenser, first disconnect electrical power to the cabinet and lift up the front louver assembly. To lift this, remove the two screws located on both sides at the bottom of the louver assembly (see figure 3). Once the screws are removed, the panel can be pivoted upwards allowing full access to the front facing condenser (see figure 4). Vacuum or brush any dirt, lint or dust from the finned condenser coil, the compressor and other cooling system parts. If significant dirt is clogging the condenser fins, use compressed air to blow this clear.

Lower louver assembly and replace the screws to hold it in place.



V. b - HINGE REPLACEMENT:

Both the door and hinge can be easily removed from the cabinet. To remove the door, remove the plug at the bottom of the top hinge. Inside the hinge there is a small screw which secures the door in place. Remove this with a flat head screwdriver and the door can then be lifted off the hinge. To remove the door portion of the hinge from the door, lift off the hinge cover and then remove the three Phillips head screws which secure the hinge in place on the door. To remove the cabinet portion of the hinge, remove the three Phillips head screws which hold it in place. On solid door units, the top hinge(s) contains a microswitch for controlling the interior lighting.

To reassemble the hinge reverse the previous procedure.

V. CARE & MAINTENANCE (cont'd)

V. c - REPLACING THE GASKETS:

To remove the gasket to be replaced, grasp it firmly by one corner and pull it out. Before attempting to install a new gasket, both the unit and the gasket itself must be at room temperature. Insert the four corners first by using a rubber mallet (or hammer with a block of wood). After the corners are properly inserted, work your way towards the center from both ends by gently hitting with a mallet until the gasket is completely seated in place (see figure 5 for proper gasket placement).




Fig. 6

NOTE: The gasket may appear too large, but if it is installed as indicated above it will slip into place.

V. d - CLEANING THE EXTERIOR:

Exterior stainless steel should be cleaned with warm water, mild soap and a soft cloth. Apply with a dampened cloth and wipe in the direction of the metal grain.

Avoid the use of strong detergents and gritty, abrasive cleaners as they may tend to mar and scratch the surface. Do NOT use cleansers containing chlorine, this may promote corrosion of the stainless steel.

Care should also be taken to avoid splashing the unit with water, containing chlorinated cleansers, when mopping the floor around the unit.

For stubborn odor spills, use baking soda and water (mixed to a 1 TBSP baking soda to 1 pint water ratio).

V. e - CLEANING THE INTERIOR:

For cleaning both stainless steel and anodized aluminum interiors, the use of baking soda as described in section "V. d" is recommended. Use on breaker strips as well as door gaskets. All interior fittings are removable without tools to facilitate cleaning.

VI. OTHER

VI. a - SERVICE INFORMATION:

Before calling for service, please check the following:

- Is the electrical cord plugged in?
- Is the fuse OK or circuit breaker on?
- Is the power switch "ON"?

If after checking the above items and the unit is still not operating properly, please contact an authorized Traulsen service agent. A complete list of authorized service agents was provided along with your Traulsen unit. If you cannot locate this, you may also obtain the name of a service agent from the Tech Service page of our website: www.traulsen.com.

If service is not satisfactory, please contact our in-house service department at:

Traulsen
4401 Blue Mound Road
Fort Worth, TX 76106
(800) 825-8220

Traulsen reserves the right to change specifications or discontinue models without notice.

VI. b - SPARE PARTS:

Spare or replacement parts may be obtained through a parts supplier or one of our authorized service agents. A complete list of authorized service agents accompanies this manual and is also posted on our company's official website @ www.traulsen.com.

VI. c - WARRANTY REGISTRATION:

For your convenience, the warranties on your new Traulsen unit may be registered with us by one of two methods. Completing the enclosed warranty card (shipped with the unit), or by filling out the on-line warranty registration form located on the Technical Service page of our website (www.traulsen.com).

VII. GENERAL USE, OPERATION & SERVICE SUMMARY

VI. a - INTRODUCTION/OVERVIEW:

The Traulsen Even Thaw is designed to be used as a thawing cabinet. While it may be utilized in a refrigeration mode, that is not its intended use. Its function is to hold the cabinet temperature in the range from 38 to 40 degrees to thaw product within the food-safe temperature zone. It has not been configured to hold colder product temperatures in the 35 to 38 deg F range as desired by some customers.

Frozen product placed into the unit will pull the cabinet temperature below the heater set point (37 deg.) and the unit will begin to function in the thaw mode. This prompts the refrigeration system to turn OFF, and the heaters to turn ON. The fans remain ON, circulating this cold air around the product, allowing for rapid thawing. When cabinet air temperature reaches the upper set point (38 deg. although the product is actually much colder), the heaters turn OFF.

As the cabinet temperature reaches the heater set point, the heat will be cycled off while the internally generated heat from the circulation fans continues to add heat to the cabinet. If sufficient cold capacity or possibly other frozen product is added to the unit and subsequently lowers the cabinet temperature more than 1 degree below the heater set point, the heat will again turn on to thaw the product.

If the cold capacity of the product no longer sufficiently pulls down the cabinet temperature below the heater set point, the cabinet temperature will slowly rise to attain the evaporator coil cut-in set point (41 deg.) and energize the refrigeration system. The unit will remain in the refrigeration mode until the cabinet temperature pulls down to the compressor cut-out set point (38 deg.). The unit will continue to operate and cycle in the refrigeration mode.

The units incorporate a mode switch located behind the louvered panel. Switching to the Refrigeration mode (switch OFF) will turn off two internal blower fans and will reduce the Thaw mode (switch ON) performance. Subsequently, switching to the Thaw mode will have reduced refrigeration performance.

The controller has been preset at the factory and should not require any adjustments. Traulsen engineering EXPECTS no changes be made to any set points or parameter settings without discussing the situation and obtaining approval to do so. Modifying the default set points could disrupt the operation/functional programming algorithm and result in erratic unit operation.

VI. b - LOADING GUIDELINES:

The Even-Thaw model can accommodate any size partial load, or up to (28) 18" x 26" pans of product (for example approximately 672 lbs. of chicken). Use of aluminum pans is highly recommended. Product should be placed on pans in one layer only to allow for proper airflow. With a full load thaw time will be between 22 & 24 hours. Overloading and/or double wrapping product will extend thaw times.

VI. c - LED LIGHTS:

The controller has two LED lights that can be useful. One is marked H, which will be lit when in the Refrigeration mode. The other is marked G and will be lit during the Thaw mode. When the H LED is lit the controller will supply line voltage to the compressor relay coil closing the N/O contacts in turn supplying line voltage to the condensing unit. When the G LED is lit the controller will supply between 3 to 30 VDC to the solid-state relay coil closing the N/O contacts in turn supplying line voltage to the mullion heater.

VI. d - CALL SERVICE LIGHT:

If lit, this indicates that one of the two temperature sensors is either OPEN or SHORTED. To check the resistance value per given temperature is correct place the sensor in an ice bath (32 deg.). The resistance value should be 100 ohms \pm 2%. There is a cabinet sensor inside the heater/blower chamber and another sensor in the evaporator coil.

VIII. EXPECTED THAW PERFORMANCE/OPERATIONAL TROUBLESHOOTING

VIII. a - INTRODUCTION:

Even thaw performance is a function of many factors, especially those involving product types and loading. As a result, actual thaw times will vary as even similar sized loads of the same product will exhibit some differences in their thawing characteristics.

VIII. b - TEST PARAMETERS:

To provide a general performance baseline, Traulsen performed some controlled testing in our lab which may provide the operator with an approximate idea on what to expect from their Even-Thaw unit. Full load batches of frozen product were used as follows:

ONE SECTION MODELS

336 lbs. of chicken, distributed between 14 tray levels. Each level consisted of 24 lbs. of product loaded into two pans (four 6 lb. pkgs. of frozen product total per level/two 6 lb. pkgs. per tray).

TWO SECTION MODELS

672 lbs. of chicken, distributed between 28 tray levels. Each level consisted of 24 lbs. of product loaded into two pans (four 6 lb. pkgs. of frozen product total per level/two 6 lb. pkgs. per tray).

VIII. c - TEST RESULTS

Under these actual load parameters, the one-section model generally required approximately 19-22 hours in order to completely thaw the entire load. The two-section model required approximately 24-26 hours to completely thaw the entire load.

VIII. d - RESULTS AS A FUNCTION OF PRODUCT MIX:

The above thaw times were based upon a mixed load of different chicken products typically found in many establishments. It is important to note that initially, all tests performed were based on a mixed load of product. This consisted of approximately 1/4 nuggets, 1/4 strips, 1/4 to 1/3 breasts. This MIXED batch thawed in the times listed above. In actual operation, thaw batches consisting of a single type of product, or other ratios of different products may require more time for thawing. Both this and larger size loads can both contribute to longer thaw times.

VIII. e - INCOMPLETE THAWING:

In operation, incomplete thawing (i.e. bags of product in which not every piece was completely thawed) has been found to usually be the result of those pkgs. respective pan level having had restricted airflow due to overloading (from stacked pkgs. or irregular shaped packages that blocks air from getting to the pkgs. closest to the cabinet interior side wall or rear). Allowing for proper air-flow around each pkgs. of frozen product should eliminate this situation from occurring.

VIII. f - EQUIPMENT ISSUES:

If improper loading has been eliminated as a possible cause for extended thaw cycle times, there are several system checks which can be done to diagnose the Traulsen Even-Thaw unit.

First, the amp draw should be checked early in the thaw cycle. Shortly after loading the unit with frozen product, the electronic control LED, "G", should be illuminated as the cabinet temp will probably be in the 30 to 34 degree F range as per the control read-out. At this time, full heat should be on. This is a 1300 watt heater, 115 vac, is about 11.3 amps. Add 4 blowers at 1.1 amps and a few amps for the controls and the total amp draw should be approximately 16 to 16.5 amps.

When the cabinet temperature reaches 36°F, the LED "G" will pulse indicating the heat is now being applied at a 50% level. At 37°F, the LED "G" will be turned off indicating thaw heat is off. This cycle will repeat until the cabinet temperature stabilizes between 37-41°F. When the cabinet temperature exceeds 41°F, the LED "H" illuminates indicating that the cabinet has switched to refrigeration cycle. The cabinet will now cycle between 37-41°F in order to maintain cabinet temperature.

Also, be certain that the thaw switch has not been turned OFF. This is located behind the louvers and has a protective guard around it. This switch can turn OFF 2 of the 3 mullion blowers and reduce airflow which reduces thaw capability. In addition, the blower wattage actually adds heat to the unit and helps augment the units thawing capability.

VIII. g - OTHER CAUSES OF EXTENDED THAW TIMES:

Some frozen products are often stored in large, irregularly shaped packages. If used, these should always be located along the outside wall with the largest packages being placed closest to, but not directly against, the wall. It is **IMPERATIVE** that such large packages not be placed up against the center mullion air ducts. This could result in blocked airflow. **REDUCED AIR MOVEMENT EQUATES TO LONGER THAWING TIMES.**

Care should also be taken to avoid pushing other pkgs. of frozen product up against the mullion sheet metal ducts. Airflow could be blocked resulting in a similar extended thaw time situation.

Another scenario to avoid is for packages to be placed inadvertently up against the outside walls. They will also block air flow down the sides of the unit. This is especially an issue with the right side wall because when the unit returns to normal refrigerated operation mode, the cold air flows from the upper right ceiling evaporator outlet, down the wall, and then mixes into the cabinet, distributed by all the mullion blowers. If the right wall is blocked, and especially if blocked near the top right of the cabinet, the cold

VIII. OPERATIONAL TROUBLESHOOTING (cont'd)

VIII. g - OTHER CAUSES OF EXTENDED THAW TIMES (cont'd):

evaporator exit air can be short circuited on to the top two or three upper right hand levels and be routed right back to the return evaporator inlet duct. Therefore, those upper shelves could get very cold and perhaps a substantial amount of product on the right side could become very cold and possibly even refreeze (as the evaporator outlet air temperature is 20 degrees F).


IX. TROUBLE SHOOTING GUIDE

FIND YOUR PROBLEM HERE	REMEDY
1. Condensing unit fails to start	a. Check if cord & plug has been disconnected.
2. Condensing unit operates for prolonged periods or continuously.	a. Are doors closing properly? b. Dirty condenser or filter. Clean properly. c. Evaporator coil iced. Needs to defrost. d. Shortage of refrigerant, call service.
3. Food compartment is too warm.	a. Check doors and gaskets for proper seal
4. Condensation on the exterior surface.	a. Check door alignment and gaskets for proper seal.
5. Compressor hums but does not start.	a. Call for service.
6. "Call Service" light is lit.	a. Call for service. A temperature sensing probe may have failed.
7. Excessively long product thaw times.	a. Review sections "VIII. e" thru "VIII. g". b. Call for service.


X. SPARE PARTS LIST

PART NUMBER	APPLIES TO MODEL(S)	PART NAME AND/OR DESCRIPTION
341-60105-00	RET132EUT-FHS	Full Height Door Gasket
SFO-17357-00	RET232EUT-FHS	Full Height Door Gasket
341-60060-00	RET232NUT-HHS	Half Height Door Gasket
341-09501-00	RET232NUT-FHS	Full Height Door Gasket
325-60003-00	RET132EUT & RET232EUT	Filter Drier
325-60003-03	RET232NUT	Filter Drier
325-60080-08	RET132EUT	TXV Valve 134a
325-60080-07	RET232NUT & RET232EUT	TXV Valve 134a
337-60006-00	RET132EUT & RET232NUT	Run Capacitor
337-60006-02	RET232EUT	Run Capacitor
378-29776-00	RET132EUT & RET232NUT	Light Bulb
378-40414-00	RET232EUT	Light Bulb
324-60027-00	All Models	Even-Thaw Controller
337-60324-00	RET132EUT & RET232NUT	Relay 2-Pole, 30 Amp
337-60324-01	RET232EUT	Relay 2-Pole, 30 Amp
337-60308-00	All Models	Sensor Probe
337-60309-00	RET132EUT & RET232NUT	Transformer
337-60309-01	RET232EUT	Transformer
337-60311-00	RET132EUT & RET232NUT	Solid State Relay
337-60311-01	RET232EUT	Solid State Relay
337-29447-00	All Models	Defogger Switch
344-60126-00	All Models	Thermometer
378-60013-00	All Models	Call Service Light
346-28924-42	All Models	Lock Keys T-42
346-13186-42	All Models	Lock Cylinder
346-13189-00	All Models	Lock Bolt
346-60017-00	All Models	Lock Keeper
346-60019-00	All Models	Lock Keeper Bracket
344-13140-01	All Models	6" High Plate Caster
351-25542-00	All Models	Caster Bolt (4 required per caster)
344-37690-00	All Models	Door Handle, Stainless Steel
344-28488-00	All Models	Hinge Cam
344-28486-00	All Models	Hinge Cover
SER-28583-00	All Models	Hinge Assembly
344-13168-01	All Models	6" High Stainless Steel Adjustable Leg
701-60933-00	RET232EUT	#1 Type Tray Slide for 18" x 26" Pans
701-60032-00	RET132EUT & RET232NUT	#1 Type Tray Slide for 18" x 26" Pans


XI. WIRING DIAGRAM ALL ONE SECTION MODELS ONLY



XII. WIRING DIAGRAM MODELS RET232NUT-FHS & RET232NUT-HHS ONLY



XIII. WIRING DIAGRAM MODELS RET232EUT-FHS & RET232EUT-HHS ONLY



XIV. WARRANTY INFORMATION

STANDARD DOMESTIC WARRANTY

TRAULSEN & CO., INC. warrants new equipment to the original purchaser, when installed within the United States against defective material and workmanship for one (1) year from the date of original installation. Under this warranty, TRAUlsen & CO., INC. will repair or replace, at its option, including service and labor, all parts found to be defective and subject to this warranty. The compressor part is warranted for an additional four (4) years. During this period TRAUlsen & CO., INC. will supply replacement compressor(s) if deemed defective, however, all installation, recharging and repair costs will remain the responsibility of the owner.

This warranty does not apply to damage resulting from fire, water, burglary, accident, abuse, misuse, transit, acts of God, attempted repairs, improper installation by unauthorized persons, and will not apply to food loss.

THERE ARE NO ORAL, STATUTORY OR IMPLIED WARRANTIES APPLICABLE TO TRAUlsen, INCLUDING BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. TRAUlsen SHALL HAVE NO OBLIGATION OR LIABILITY FOR CONSEQUENTIAL OR SPECIAL DAMAGES, GROWING OUT OF OR WITH RESPECT TO THE EQUIPMENT OR ITS SALE, OPERATION OR USE, AND TRAUlsen NEITHER ASSUMES NOR AUTHORIZES ANYONE ELSE TO ASSUME FOR IT ANY OBLIGATION OR LIABILITY IN CONNECTION WITH THE EQUIPMENT OR ITS SALE, OPERATION OR USE OTHER THAN AS STATED HEREIN.

INTERNATIONAL COMMERCIAL WARRANTY

(for Canadian warranties see domestic US warranty)

TRAULSEN & CO., INC. warrants to the original purchaser the Refrigeration Equipment manufactured and sold by it to be free from defects in material and workmanship under normal use and service for a period of one (1) year from date of shipment. Under this warranty, TRAUlsen & CO., INC. will reimburse the purchaser for the replacement of any part of said equipment (excluding dryers & refrigerant gas) which then proves to be defective. This warranty is void if said equipment or any part thereof has been subject to misuse, damage in transit, accident, negligence or alteration.

TRAULSEN'S standard warranty does not apply to Export Sales. Rather, for a period of one (1) year from date of original installation not to exceed Fifteen (15) months from date of shipment from factory, TRAUlsen:

will replace, F.O.B. factory, any defective parts normally subject to warranty.

will not cover the cost of packing, freight or labor such costs being the sole responsibility of the dealer.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EITHER EXPRESSED OR IMPLIED AND CONSTITUTES TRAUlsen'S FULL OBLIGATION AND LIABILITY. WARRANTIES NOT AVAILABLE ON REMOTE MODELS.

XV. INDEX

<u>A</u>		<u>M</u>	
		Mullion Air Ducts	6
<u>B</u>		<u>N</u>	
Batch Loading	4		
Blower Switch	4		
<u>C</u>		<u>O</u>	
Call Service Light	6	Operational Troubleshooting	7
Cleaning	5 - 6		
Casters	2	<u>P</u>	
Cord & Plug	3	Power Supply	3
Clearance	3	Process Loading	4
Condenser, Cleaning The	4	Product Mix - Issues	6
<u>D</u>		<u>R</u>	
		Refrigerations System	3
<u>E</u>		Return Authorization	2
Even-Thaw Operation	3	<u>S</u>	
Evaporator Outlet	6	Serial Tag	1
Extended Thaw Times, Causes Of	6	Spare Parts List	9
<u>F</u>		<u>T</u>	
Fan Switch	6	Temperature Scale Adjustment	4
<u>G</u>		Troubleshooting	6-7
Gasket Assembly	4	Tray Slides	3, 7
Gaskets, Replacing The	4	<u>U</u>	
<u>H</u>		<u>V</u>	
Heaters	3	Vinyl, Protective Covering	2
Hinge, Replacement	4	<u>W</u>	
<u>I</u>		Warranty Statement	
Inside Door Pan	4	12	
Interior Arrangements	3	Warranty, Registration	5
<u>J</u>		Wiring DiagramS	10-11
<u>K</u>		<u>X</u>	
<u>L</u>		<u>Y</u>	
LED Lights	6	Vertical Gasket Retainer	4
Legs	2	<u>Z</u>	
Loading Guidelines	6		
Louver Assembly	4		

HOURS OF OPERATION:

Monday thru Friday 7:30 am - 4:30 pm CST



Quality Refrigeration

Traulsen

4401 Blue Mound Road Fort Worth, TX 76106

Phone: (800) 825-8220 Fax-Svce: (817) 740-6757

Website: www.traulsen.com